











Tefal®

VERSALIO DELUXE







9

10

2



Fry



Deep fry



Fry

0,5 L




Deep fry


2 L



11



12



13




Fry

< 0,5 L



Deep fry

1 L ➔ 2 L



14


3




Deep fry



Max 1000 g




Max 750 g





Deep fry




24




25




26




27




28




29



30



31






32



33



34



5 Deep fry / 180 °C



Deep fry



 2 L maxi			
	1000 g	15-16 min	4
	550 g	10-11 min	
	750 g	13-14 min	
	400 g	7-8 min	



6 Fry / 160 °C



Fry

 0,5 L maxi		
	15 min	4
	30 min	6




7



Sauté

Sauté / 130 °C

x1	10 min	4



8



Simmer

Simmer / 100 °C

30 min	4



9



Boil/Pasta

	
30 min	4



10



Rice/Risotto







	
15 min	4




11**Braise****Braise**


40 min	4







60



61







62



63



64







76



77



78



79

